



Product Descriptions

① Front Panel Configuration



- 1. Display** : The 4-digit shows channel number or menu state in normal mode, shows local time in standby mode.
- 2. STANDBY / REMOTE Indication LED (RED / GREEN)** :
The LED (RED) lights on in standby mode. / The LED (GREEN) lights on when a key on the Remote Control is pressed.
- 3. Remote Sensor** : Receives signal from remote controller.
- 4. USB** : Use it when connecting to external USB storage device.
- 5. Power Button** : Press to switch between STANDBY and POWER ON modes.

② Rear Panel Configuration



- 1. D/C power socket** : Connects the adaptor
- 2. LNB IN** : Use to connect a satellite antenna.
- 3. SPDIF** : Connects to the audio system using a S/PDIF cable. (digital audio)
- 4. HDMI** : Connects to the TV by using a HDMI cable for the best quality picture and audio.
- 5. Ethernet** : Local area network port for direct computer connection.
- 6. USB** : Use it when connecting to external USB storage device.
- 7. RS-232C** : Serial port for firmware update and data transfer.
- 8. Common Interface** : To receive other pay-tv service you need a CA-Module(Viaccess, Irdeto, Nagravision, etc.) and a smart card from the service provider.
- 9. Smart Card Reader** : Insert smart card for encrypted service access.
- 10. A/V OUT** : Connects to the TV or VCR using a optional RCA cable
(Stereo audio output / White, Red, Composite video output / Yellow)

Quick Guide

EniBox

③ Packaging Contents




1. EniBox
2. Remote Control
3. Batteries
4. Power adapter
5. HDMI Cable
6. Quick Guide



* Please check all package contents before using your product.

④ Connecting diagram



Dish Connection

- Connect the cable from the satellite dish to LNB IN.

Digital A/V Output Connections

- Connect the HDMI Cable to the HDMI Connector of your TV.
- Connect SPDIF to Digital audio input of the equipment. (Digital Audio)

Analog A/V Output Connections

- Connect the RCA to the RCA input of your TV.