

Thomson RCU observations

Please check RCU operation, if observed power – mute buttons replaced functionality.

Please check DIP switch settings. We found 2 variants of the DIP switch settings.

If the actual one not working, try the other mode. As we tested, we see at some RCUs works the other DIP switch mode.

On the picture below you can see the 2 DIP switch mode: (010, 100)

